




SERVICE MANUAL

MW/LW/SW/FM


Hi-Fi Stereo Receiver

MODEL tfs 301



Specifications are subject to change without notice.


CABINET EXPLODED VIEW



CABINET REMOVAL



1. Remove four screws on the cabinet side. (1) x 4
2. Remove two screws on the cabinet rear. (2) x 2
3. Pull the upper cabinet to backward.
4. Remove five screws on the front panel. (3) x 2 (4) x 3
5. Remove all screws (includes foot screws) from the lower cabinet.

HF-301 (FM AM Frontend, FM AM IF Amp. FM-MPX P. C. Board)




Audio Amp. P. C. Board


Equalizer Amp. P. C. Board




CIRCUIT DIAGI



DIAGRAM




COMPONENT DIAGRAM



DIAL CORD STRINGING

The overall length of a dial cord: 1100mm



Main Pulley (with Variable Capacitor) Position:

Turn counter-clockwise to end, and then string
1 = 8 order.

